

Magnetic Field Vector Measurements Using Doppler-Free Saturation Spectroscopy

FUSION Diagnostics Program Review (Virtual)
March 5, 2021

Elijah H. Martin, Oak Ridge National Laboratory




David C. Donovan, University of Tennessee - Knoxville



U.S. DEPARTMENT OF
ENERGY

Team members and roles

- ▶ Elijah H. Martin
 - Diagnostic design and assembly
 - Performance verification via laboratory demonstration
 - Identification of concept teams
- ▶ David C. Donovan
 - Subsystem performance verification



High-level motivation and capabilities of the DFSS diagnostic

Provide experimentally measured equilibrium B-field data needed to optimize and accelerate the fusion-concept.


Applicability

1. Atomic H/D neutrals ($\geq 10^{10} \text{ m}^{-3}$)
2. Optical access at two locations
3. B-Field ≥ 10 to 20 Gauss


Capability

1. $B_{||}$ magnitude/polarity (± 5 Gauss)
2. B_{\perp} magnitude (± 5 Gauss)
3. mm (\perp) to cm ($||$) resolution
4. 5 to 20 ms temporal resolution



Physics of DFSS



- I. Two laser beams are generated from a single source, these beams are referred to as the **pump** and **probe**.
- II. The beams are aligned such that they are counter-propagating at a small angle ($\theta=1-3^\circ$) and overlap at the desired measurement location.
- III. The probe beam intensity is measured as the laser frequency is swept.






DFSS selectively accesses atoms in velocity space



Local & $|E| < 10 \text{ V/cm}$
 $|B| < 10 \text{ Gauss}$


DFSS design

- ▶ System consists of:
 - 3' x 6' optical table
 - 19" equipment rack
 - Two mobile optical tables (2' x 2')
- ▶ Laser is connected to mobile optical tables via PM fiber
- ▶ Mobile optical tables:
 - Shape and steer the pump beam
 - Shape and collect the probe beam




DFSS performance verification

- ▶ The performance of the DFSS diagnostic will be verified using an existing magnetized plasma test stand at ORNL.



$$i\hbar \frac{\partial \Psi}{\partial t} = \hat{H} \Psi$$

— FIT —→




Plasma Test Stand



- ▶ Performance metrics:
 - 2D measurement of known magnetic field with <10 Gauss accuracy
 - Temporal resolution: 5 to 10 ms (localized) and 0.5 to 1 s (2D)
 - Spatial accuracy: 1's mm

Deployments to fusion experiments

- ▶ Two deployments have been funded through the INFUSE program:
 - **TAE Technologies Inc. – C-2W**
 - Deployment scheduled for July 2021
 - **Princeton Fusion Systems – PFRC-II @ PPPL**
 - Deployment scheduled for early 2022
- ▶ Future deployments (unfunded):
 - **University of Wisconsin, Madison – WHAM**



Nat. Comm. 9 (2018) 691